

Rostra Trouble Shooting Tips

250-9000 Cruise Control Switch Kit

1. Check black and green wires with meter for ground no higher than 3 ohms resistance
2. Check Red wire for ignition 12volts
3. With everything connected check, white wire voltages at brain box in harness
 - Off: 5volts on white which comes from ECM**
 - On: 3.7volts on white**
 - On, set pressed: 2.2volts on white**
 - On, Resume pressed 2.8volts on white**
4. Follow instructions in Form #5065 on 06 Aveo and Wave
5. Form #5072 on 06-08 Forenza, Reno, and 08 Aveo and Wave,
6. Any voltages not shown, replace kit.