

250-9004 Cruise Control Switch Kit

1. Check power wires red & green with meter +12 volts when key is on.
2. Check ground black wire with meter resistance no higher than 3 ohms.
3. Check white wire connection off cruise harness to gray wire position 8 off 40 pin connector off vehicle.

Leave unit connected as is, but measure voltage between white cruise wire and ground. With ignition on, voltages should be:

Cruise OFF: 0V

Cruise ON: 0.37V - 0.77V

SET held, with Cruise ON: 2.3V - 3.7V

RES held, with Cruise ON: 1.1V - 1.9V

If the voltage measures high regardless of the buttons pressed, the connection to the ECM needs to be confirmed (our white cruise wire.)

If the voltage measures low regardless of the buttons pressed, verify green cruise wire to ignition power.

If all connections are correct, replace kit.

6/02/2008