

**ROSS™ CUSTOM KIT APPLICATION GUIDE**

<b>MAKE</b>	<b>MODEL</b>	<b>YEAR</b>	<b>LOCATION</b>	<b>PART NUMBER</b>	<b>ADDITIONAL PARTS</b>	<b>PAGE NUMBER</b>
<b>DAIMLER CHRYSLER CORPORATION</b>						
Dodge	Durango	2003	Hitch	250-1594QC	250-2572	9
<b>FORD MOTOR COMPANY</b>						
Ford	Expedition XLT/ Eddie Bauer	2003	Hitch	250-1594QC	250-2576	7
Ford	Explorer XLT/ Limited/Eddie Bauer	2003	Hitch	250-1594QC	250-2576	7
Mercury	Mountaineer*	2003	Hitch	250-1594QC	250-2576	7
<i>*NOTE: For vehicles with the upgraded towing package option only.</i>						
<b>GENERAL MOTORS</b>						
Chevrolet	Suburban	2003	Bumper	250-1594QC	250-2571	3
Chevrolet	Tahoe	2003	Bumper	250-1594QC	250-2571	3
Chevrolet	Trailblazer	2003	Hitch	250-1594QC	250-2574	5
Chevrolet	Trailblazer EXT	2003	Hitch	250-1594QC	250-2574	5
Chevrolet	Avalanche**	2003	Bumper	250-1594QC	250-2575	11
GMC	Yukon XL	2003	Bumper	250-1594QC	250-2571	3
GMC	Yukon	2003	Bumper	250-1594QC	250-2571	3
GMC	Envoy	2003	Hitch	250-1594QC	250-2573	5
GMC	Envoy XL	2003	Hitch	250-1594QC	250-2573	5
<i>**NOTE: For vehicles with body hardware (plastic cladding)</i>						
<b>TOYOTA</b>						
Toyota	4Runner	2003	Bumper	250-1594QC	250-2592	13