



Tech/Product Bulletin

August 1, 2007

Hot Cruise Applications:

- 07 Chevy Cobalt
- 07 Chevy Equinox ETC
- 05-07 Chevy Express Van
- 07 Chevy Sierra
- 07 Chevy Silverado
- 07 Chevy Uplander
- 07 Kia Rio
- 05-07 Pontiac G5
- 05-07 Pontiac G6
- 07 Pontiac Torrent
- 07 Suzuki SX4



New Product Releases: Back Up Cameras

250-8033: Heavy Duty **Infra-Red** Camera w/3.5" LCD Monitor



250-8122: Heavy Duty **Infra-Red** Camera w/5" Windshield Mount LCD Monitor

250-8075: 07 GM 900 Series Navigation Interface Harness w/Shrouded Camera



250-8076: 07 Toyota Camry/Solara Navigation Interface Harness w/Shrouded Camera

New Product Releases: Cruise Controls & Accessories

250-9003: 07 Pontiac Torrent, Chevy Equinox ETC

250-9004: 07 Uplander ETC

250-4379: Signal Divider for 07 Silverado & 07 Sierra

Trouble Shooting Tips:

250-1775 Cobalt/G5/G6

1. For the gray wire attachment in the BCM, there are two connectors that look the same. Always use connector with white/black wire in position 62, insert gray in position 61 beside white/black.

250-9003

1. Check power with meter +12 volts when key is on.
2. Check ground with meter resistance no higher than 0.09.
3. Check green wire connection off cruise harness to position "D" gray wire off vehicle.

250-9004

1. Check power wires red & green with meter +12 volts when key is on.
2. Check ground black wire with meter resistance no higher than 0.09.
3. Check white wire connection off cruise harness to gray wire position 8 off 40 pin connector off vehicle.

Coming Soon . . .05-07 Chevy Express, 07 Kia Rio, 07 Suzuki SX4 Cruise