

2000-2003 Ford Windstar Ross wire connection to the reverse light

For multiplex light system, you will have +12Volts on both sides of the reverse wires, Gray/Red and White/yellow.

Use a low current relay or equivalent (5 Amp). Single pull – single throw

1. Connect both reverse wires Gray/Red and White/yellow to the coil side of the relay (terminals 85 and 86).
2. Connect the common terminal 30 to a chassis ground.
3. Connect terminal 87 to the black wire of the ROSS module harness.
4. Connect the Blue wire of the ROSS module harness to the Gray/Red wire of the reverse light.

