

2005-2008 TOYOTA COROLLA/MATRIX OE-STYLE CRUISE CONTROL SWITCH TEMPLATE INSTRUCTIONS

- 1) Disconnect Negative Side of Battery at least **90** seconds prior to installation. Remove Steering Wheel Airbag utilizing **Torx 30 Driver**. Refer to **Cruise Switch Installation Instructions** and observe proper **Airbag** removal.
- 2) Cut-Out **Switch Hole Location Template** below and place on Right Side of Steering Wheel Shroud to mark the four corners of the **Switch Hole Location Square**.
- 3) Drill-Out four corners of **Switch Hole Location Square** with a **1/4"** Drill Bit. Cut-out remaining plastic from inside the the **Switch Hole Location Square**.
- 4) Smooth edges of **Switch Hole Location Square** for appearance and install **OE-Style Cruise Switch** as directed in **Cruise Switch Installation Instructions**.

Form #4903, Rev. B, 03-04-14

