


INSTALLATION MANUAL 250-8414

REVERSE CAMERA/VIDEO INTEGRATION MODULE

This manual shows the install into a single applicable vehicle. Other vehicle disassembly will vary. wiring remains the same with all vehicles.

See application guide for applicable vehicles



INTERFACE DIP SWITCH SETTINGS



DIP	<u>ON</u>	<u>OFF</u>
DIP 1	A/V 1 ON	A/V 1 OFF
DIP 2	A/V 2 ON	A/V 2 OFF
DIP 3	A/V 3 ON	A/V 3 OFF
DIP 4	AFTERMARKET CAMERA	OEM CAMERA
DIP 5	4.2" SCREEN	8"SCREEN
DIP 6	TOUCH SCREEN CALIBRATION ON	TOUCH SCREEN CALIBRATION OFF

- DIP SWITCH SETTINGS MUST BE PERFORMED WITH UNIT POWERED OFF.
 IT WILL NOT CAUSE DAMAGE, BUT THE FUNCTION WILL NOT BE
 RECOGNIZED UNTIL POWER CYCLES.
- YOU MUST CALIBRATE THE TOUCHSCREEN IN ON THE INTERFACE AS WELL AS THE NAVIGATION BRAIN FOR 4.2" MODEL.

A/V FUNCTIONS

 THIS UNIT SUPPORTS THREE AUDIO/VIDEO INPUTS. AND ONE AUDIO/VIDEO OUTPUT.

RADIO CONTROL PANEL



RADIO CONTROL PANEL BUTTON FUNCTIONS

HOME BUTTON FUNCTIONS ARE DETERMIDED BY THE "HOME" BUTTON
 SELECTED IN THE INTERFACE SETTINGS MENU. YOU CAN SELECT ANY
 BUTTON TO BE THE "HOME" BUTTON IN THE HOME BUTTON
 PROGRAMMING SECTION OF THE INTERFACE SETTINGS.

BUTTON	WHEN PRESSED IN NAV SCREEN	WHEN PRESSED IN FACTORY SCREEN
НОМЕ	1 SEC = SWITCH BETWEEN A/V SOURCE	3 SEC = SWITCH TO INTERFACE
BACK	SWITCH TO PREVIOUS FACTORY SCREEN	FACTORY FUNCTION
RADIO	THIS WILL SWITCH SOURCE WITHOUT EXITING NAV SCREEN	FACTORY FUNCTION
MENU	BACK TO MAIN MENU	FACTORY FUNCTION
<< >>	THIS WILL SEEK WITHOUT EXITING NAV SCREEN	FACTORY FUNCTION




REMOVE TRIM BEZEL AROUND RADIO.
 SET ASIDE.



 REMOVE FOUR 7MM SCREWS FROM THE CORNERS OF THE CONTROL PANEL.



 GENTLY PULL ON CONTROL PANEL TO RELEASE THE TWO CLIPS LOCATED ON THE SIDES.



 UNPLUG ALL PLUGS FROM CONTROL PANEL AND SET IT ASIDE.



PLUG SUPPLIED T-HARNESS (TWO)
 INTO THE CONNECTIONS ON THE BACK
 OF THE CONTROL PANEL.



T-HARNESSES PLUGGED IN.



 PLUG MOLEX CONNECTOR FROM T-HARNESS INTO THE MAIN HARNESS.



• ROUTE MAIN HARNESS TO DESIRED LOCATION OF INTERFACE BOX.



PLUG TWO CONNECTORS INTO
 INTERFACE. THE OTHER CONNECTORS
 SHOWN IN THIS PICTURE (3PIN & 2PIN)
 ARE FOR DVD IR AND ARE NOT NEEDED
 UNLESS INSTALLING AN AFTERMARKET
 DVD PLAYER NEEDING TOUCH
 CONTROL.



PLUG LVDS T-HARNESS INTO LVDS
 SOCKET. THERE ARE GUIDES LOCATED
 ON PLUG TO ALIGN IT CORRECTLY. BE
 SURE TO PLUG IN CORRECTLY. DO NOT
 FORCE. ROUTE THE CABLE AND SECURE
 WITH CABLE TIES.



MADE TO INTERFACE AND
NAVIGATION BOX, PLUG THE LVDS
AND 10 PIN T-HARNESSES BACK INTO
THE CONTROL PANEL AND SNAP
CONTROL PANEL BACK INTO THE DASH.



 TURN THE IGNIGTION ON, ONCE THE UNIT BOOTS AND THE DISPLAY IS ACTIVE, PRESS AND HOLD THE "HOME" KEY FOR 20 SECONDS UNTIL THE INTERFACE SWITCHES TO NAVI MODE.



 ONCE IN THE NAVI MODE PRESS AND HOLD THE TOUCH SCREEN FOR ABOUT 8 SECONDS UNTIL THE INTERFACE MENU DISPLAYS.



 ONCE INSIDE THE MENU, CHOOSE THE HOME BUTTON LEARNING BY PRESSING START.



ONCE THIS IS DONE, PRESS THE HOME BUTTON ON THE RADIO AGAIN TO LEARN THAT BUTTON FOR THE SWITCHING OF NAVIGATION, A/V1,2,3, AND FACTORY DISPLAY. ONCE THIS IS DONE IT WILL ONLY TAKE 3 SECOND TO SWITCH THE INTERFACE WHEN PRESSING THIS BUTTON.



 YOU CAN ALSO ADJUST THE BRIGHTNESS AND CONTRAST OF THE INTERFACE HERE.