


General Applicability

All Models

Item #	Qty.	Description
1. 250-2758	1	Cruise Control Module
2. 250-2760	1	Switch Harness
3. 250-2759	1	Main Wiring Harness
4. 250-2761	1	Pedal Interface Harness
5. 250-2762	1	Hardware Kit
6. 250-3742	1	Control Switch

Kit Contents/Service Parts



Contents of Hardware Bag, 250-2762

Qty	Description
1	T-taps, 18-22 AWG Female
8	Wire Zip Ties
1	Adhesive VHB Tape 3 X 3
1	Male Spade Terminal 18-22 AWG
2	Weather sealant
6	In-Line Connector, 18-22 AWG
1	Extension Harness

Additional Items Required For Installation

Recommended Tools

Safety Tools	
Gloves, Safety Glasses	
Special Tools	
Volt-Ohm Meter	
Installation Tools	
Pliers	For t-taps
Crimping Tool	For spade terminals
Side cutter	To cut wire ties
Drill Bit or Knockout Punch	9.5mm or 3/8" (for switch)
10mm wrench	
Special Chemicals	

Conflicts

Note:

Recommended Sequence of Application

Item #	Accessory
1	
2	
3	

Legend

STOP **STOP:** Damage to the vehicle may occur. Do not proceed until process has been complied with.

+ **OPERATOR SAFETY:** Use caution to avoid risk of injury

! **CRITICAL PROCESS:** Proceed with caution to ensure a quality installation.

→ **GENERAL PROCESS:** This highlights specific processes to ensure a quality installation.

🔧 **TOOLS & EQUIPMENT:** This calls out the specific tools and equipment required for this process

Section I – Installation Procedure

A. Pre-Installation Suggestions

- ✚ 1. It is advisable to disconnect the negative battery cable for 3 minutes before beginning installation, to avoid unintended air bag deployment. Note and record any anti-theft radio codes prior to disconnecting. **Figure 1**



- 2. Remove the driver side lower dash and kick panels. Remove the steering wheel shroud. **Figure 2**

B. Install Electronic Module

- ➔ 1. Apply the large supplied piece of double-sided adhesive tape to the Cruise Control Module.
- ⚠ 2. Plug in the **Main Wiring Harness, Switch Harness, and Pedal Interface Harness** onto mating connectors of the Cruise Control Module. **Figure 3**
- 3. Place the Cruise Control Module in the secure location behind the driver side dash area as shown in **Figure 4**.
- 4. Route the **Pedal Interface Harness** through steering column and down to the accelerator.




Figure 1




Figure 2




Figure 3





Figure 4

5. Locate the 6 pin **plug and mate connectors** on the Pedal Interface Harness. Remove the accelerator 6-pin connector and apply to mating connector of Pedal Interface Harness. Apply the other connector to the accelerator.

Figure 4



C. Wiring Connections






1. Locate the following wires to connect to the main harness from the control module:

Function	See Fig.	Vehicle Color
IGN	5	WHITE/LT. BLUE
BRAKE +	6	YELLOW/RED
BRAKE -	6	VIOLET/WHITE
GROUND	7	BLACK/VIOLET
VSS	8-10	BROWN/GREEN
CLUTCH SWITCH	11	GREEN/VIOLET





2. Use the supplied self stripping connectors or T-tap to connect from the Main Harness to vehicle wire:

Function	Cruise Harness Color	Vehicle Wire
IGN	RED	LT.BLUE/WHITE
BRAKE +	BLUE	YELLOW/RED
BRAKE -	BROWN/WHITE	VIOLET/WHITE
VSS	VIOLET	BROWN/GREEN
CLUTCH SWITCH	WHITE	GREEN/VIOLET

3. Apply the **Black Ground Wire** from the Main Harness to the Vehicle Ground Point at the kick panel. **Figure 7**



4. **VSS:** For reference, find the metal bracket in front of the gray and blue connectors at the center of the engine compartment. **Figure 8.** Locate the gray 2-pin or (3-pin manual transmission) connector on the transmission below the bracket. **Figure 9. Note: The 3-pin connector will be covered with foil tape.** Connect the **Violet Wire** from the Main Wiring Harness to the Blue extension wire using the male spade terminal (both supplied in hardware kit). Connect extension harness to **Brown/Green Wire (VSS)** of the connector. **Apply the supplied weather sealant to the connection in the engine compartment.** Be sure all of connection is sealed properly. **Figure 10**
5. **Clutch Switch for Manual Transmissions:** Locate the black 2-pin connector on the clutch switch. Connect the **White Wire** from the Main Wiring harness to the **Green /Violet Wire** of the clutch switch. Secure Cruise Control and Switch Interface Module harnesses with zip ties away from moving parts. **Figure 11**



D. Install Control Switch



1. Use the **level wedges** on the Control Switch at an angle template to drill a 3/8" or 9.5mm hole in the lower shroud of the steering column cover. Position lock-washers as shown. **Figures 12-13**
2. Apply nut and position Control Switch for driver's best view.
3. Assemble (2) 3-pin connectors from the sack parts to the mating wire colors on the Control switch harness. Use the diagram to mate the module harness to switch harness. **Figure 14**
4. Route the assembled Control Switch harness to the mating connector of the Cruise Control module.
5. Secure the Control Switch harness with zip ties away from moving parts.




Figure 12




Figure 13

E. Testing



1. Reconnect negative battery cable and torque to 35 in*lbs. Reenter anti-theft radio codes.



2. Turn ignition on. Apply the on/off button of Cruise Control Switch.

F. Reassembly



1. Reinstall all removed pieces taking care to ensure harnesses and wiring connections are properly secured.
2. Make sure all harnesses are not pinched or bound by trim pieces.




Figure 14



Figure 15

FORD

FOCUS

2008-2009

ELECTRONIC CRUISE KIT

Part Number: 250-1840

AUTOMATIC AND MANUAL TRANSMISSION

Notes:

FORD

FOCUS

2008-2009

ELECTRONIC CRUISE KIT

Part Number: 250-1840

AUTOMATIC AND MANUAL TRANSMISSION

Notes:

